



INSTRUCTIONS - ENGLISH

Please use an Allen key, or alternatively a cordless drill set to a low torque. All bolts should be screwed in without resistance. If you feel resistance, unscrew the bolt. Failing to follow these instructions may result in damage to the tabletop or inserts. Assemble the table where it is to be placed. Work with at least 2 people. Work on a soft surface to protect the wooden parts and the tabletops.

1. Fix the beams [A] onto the A-frames [B] by pushing the beams into the connectors from above. Ensure that the top of the beam is level with the A-frame.
2. Use the bolts to fix the steel brackets to the beams and the A-frames. Do not fully tighten the bolts at this stage.
3. Place the tabletops on the supporting frame. Fix all brackets and the steel assembly plates to the tabletops. Do not fully tighten the bolts!
4. Ensure that the tabletops are straight and closely aligned. First securely tighten the brackets closest to the adjacent tabletops. Now securely tighten the remaining bolts.
5. Carefully move the table to the desired location. Make sure enough people help, to avoid overloading the joints. Ensure that the frames are upright. If necessary, use the adjustable feet to compensate for uneven ground.

Ensure constant humidity of between 50% and 60%, to prevent the solid wood parts from rubbing or cracking. Maintenance instructions are available on our website. Please sort and compact the packaging materials before disposal. Thank you.

DUM BV T +31 [0]20 4890104 info@dumoffice.com www.dumoffice.com

INSTRUCTIES - NEDERLANDS

Gebruik bij voorkeur een inbussleutel of een accuboer ingesteld op een laag koppel. Bouten moeten zonder weerstand worden ingeschroefd. Als er weerstand is, draait u de bout er weer uit. Als deze instructies niet worden opgevolgd, kan dit schade toebrengen aan het tafelblad of de inserts. Monteer de tafel op de locatie waar deze moet komen te staan. Werk met minimaal 2 personen. Zorg voor een zachte ondergrond om de houten onderdelen en de tafelbladen te beschermen.

1. Monteer de balken [A] op de A-frames [B] door de balken van bovenaf in de connectors te drukken. Zorg dat bovenzijde balk gelijk loopt met het A-frame.
2. Bevestig de stalen hoekprofielen met de bouten op de balken en de A frames zonder deze helemaal vast te draaien.
3. Leg de bladen los op het onderstel. Bevestig alle hoekprofielen en de stalen montageplaten aan de tafelbladen. Draai deze ook niet vast!
4. Zorg dat de bladen recht en strak tegen elkaar aan liggen. Draai eerst de dichtstbijzijnde profielen van de naast elkaar liggende tafelbladen vast. Draai nu alle bouten stevig vast.
5. Verplaats de tafel voorzichtig naar de gewenste locatie. Zorg dat er daarbij voldoende mankracht aanwezig is zodat de verbindingen niet worden overbelast. Zorg dat de frames goed recht staan. Oneffenheden in de vloer kunnen worden opgevangen door de stelvoeten.

Zorg voor een constante luchtvochtigheid tussen de 50 en 60% zodat de massief houten delen niet gaan scheuren of kieren. Instructies voor onderhoud vindt u op onze website. Zorg dat het verpakkingsmateriaal compact en gescheiden wordt afgevoerd. Hartelijk dank.